



34. 3oz Harmony™ Cup
2.75 dia x 2, 3oz
Pack 12
DCS037WHP23

35. 4.5" Harmony™ Saucer
4.5 dia x .25
Pack 12
DCS038WHP23

36. 3.75" Harmony™ Spoon
3.75 x 1
Pack 12
FCS004BSS23



37. 3.75" Harmony™ Fork
3.75 x 1
Pack 12
FSF014BSS23

Fits 3oz Harmony™ Cup



38. 10oz Harmony™ Cup
4 dia x 2.75, 10oz
Pack 12
DCS039WHP23

39. 6" Harmony™ Saucer
6 dia x .75
Pack 12
DCS040WHP23

40. 5.5" Harmony™ Spoon
5.5 x 1.5
Pack 12
FCS005BSS23



41. 16oz Harmony™ Cup
5 dia x 3, 16oz
Pack 6
DCS041WHP22

42. 7" Harmony™ Saucer
7 dia x 1
Pack 6
DCS042WHP22

43. 6.5" Harmony™ Spoon
6.5 x 1.5
Pack 12
FSS014BSS23



Ask about decal customization!



44. 12oz Seattle Mug
3 dia x 4.5, 12oz
Pack 12
DMU008WHP23



45. 14oz Seattle Cup
4.5 dia x 3, 14oz
Pack 12
DCS033WHP23

46. 7" Seattle Saucer
7 dia x 1
Pack 12
DCS034WHP23



47. 6oz Seattle Cup & Saucer
Cup: 3.25 dia x 2.25, 6oz
Saucer: 5.5 dia x 1
Pack 12
DCS005WHP23



48. 2.5oz Seattle Cup & Saucer
Cup: 2.5 dia x 1.75, 2.5oz
Saucer: 4.75 dia x .75
Pack 6
DCS043WHP22