



155. 4.25" Rectangle Footed Kyoto™ Dish
4.25 x 3 x 1, 2oz
Pack 12
DSD031WHP23



156. 3.5" Rectangle Kyoto™ Dish
3.5 x 1.75 x .75, 1oz
Pack 12
DSD029WHP23



157. Rectangle Dish
4 x 2.5 x 1, 2oz
Pack 12
DSD025WHP23 white
DSD025BEP23 eurowhite®



NEW
ITEM

158. 2.75" Square Spiral® Dish
2.75 x 2.75 x 1.25, 3oz
Pack 12
TSH007WHP23 white
TSH007BEP23 eurowhite®
TSH007BKP23 ink



159. 2.5oz Square Mod® Ramekin
2.5 x 2.5 x .75, 2.5oz
Pack 24
DSD028WHP24 white
DSD028BEP24 eurowhite®



160. 3.25" Square Tall Kyoto™ Dish
3.25 x 3.25 x 1.5, 4oz
Pack 12
DSD026WHP13 white
DSD026BEP13 eurowhite®



161. 4.5" Square Footed Kyoto™ Dish
4.5 x 4.5 x 1.5, 4oz
Pack 6
DSD032WHP22 white
DSD032BEP22 eurowhite®



162. 3" Square Kyoto™ Dish
3 x 3 x 1, 1oz
Pack 12
DSD024WHP13 white
DSD024BEP13 eurowhite®



163. 3.5" Square Kyoto™ Dish
3.5 x 3.5 x .75, 1oz
Pack 12
DAP039WHP23 white
DAP039BEP23 eurowhite®